


TOUCH KEY INSTRUCTION MANUAL



operating instructions

- after the remote touch key is connected to the power, the backlight is blue that shows state normal.
- press the operating key after connected to the power, and the indicator light will blink. press key of remote and program with access control.
- press operating key for 8s to clear the remote.
- touch key without remote control can work directly after connected to the power.

fault description

if the backlight blue and red state and touch it but donot respond, please rearrange the line if all indicator lights work normally, and touch it relay with a sound, cannot open the door, please check whether the signal line is correct.
 ⚠ Note: please install the touch key first, then connected to the power.

wiring diagram

