
130mm
Outline of rubber seal
17.5mm
R7mm
R4mm
19 mm
13mm
Outline of lockcase
R4mm
13 mm
35 mm
The edge of door
Hole Draw of Lock
The edge of door
35 mm
13 mm
19 mm
R4mm
R7mm
Outline of lockcase
13mm
R4mm
17.5mm
Outline of rubber seal
130mm

Code Lock for Glasses Door



Parts List:

1. lock body of outside door
2. lock body of inside door
3. rubber mat
4. spindle of lock
5. hull of fixing base
6. inner hull of fixing base
7. middle plate of fixing base
8. screws (2pcs)
9. screws of fixing base (2pcs)
10. strike plate of doorframe
11. screw (2pcs)



Special Instruction

Please check each part is normal before you install.According to different requirements to set up the code,because the lock code is not set up by factory .For details,please refer to the code changing instruction.Then,please insert the lock spindle into the square hole of outside door lock body.(need insert the bottom of square hold,because have 2 levels inside of square hole),please input right code,and then turn handle to let it rebound.

Before installing the lock body,the end user should make sure the left or right direction of installing handle.